






DOUBLE GANG COMBINATION




TRIPLE GANG COMBINATION




FOUR GANG COMBINATION



FIVE GANG COMBINATION




PLANO SERIES




FLUSH MOUNTING TYPE




SOCKET OUTLET
16A 250V~
Article No. E151



UNIVERSAL SOCKET OUTLET
13A 250V~
Article No. E15B



DOUBLE CHANGE OVER SWITCH
10AX 250V~
Article No. E164



THREE POLE SWITCHES WITH
INDICATOR LAMP
16AX 400V~
Article No. E16E




TELEPHONE SOCKET OUTLET
(RJ 11)
Article No. E171



DUAL UNIVERSAL NETWORK
SOCKET OUTLETS CAT.5e (RJ45)
Article No. E177




SATELLITE ANTENNA SOCKET OUTLET
Article No. E184



DO NOT DISTURB INDICATOR
230V~
Article No. E141




SOCKET OUTLET
WITH CHILD PROTECTION
16A 250V~
Article No. E154



SINGLE SWITCH
10AX 250V~
Article No. E161



SINGLE PUSH BUTTON SWITCH
10AX 250V~
Article No. E165



INTERMEDIATE SWITCH WITH
INDICATOR LAMP
10AX 250V~
Article No. E16J




SINGLE NETWORK SOCKET OUTLET
Cat. 5e (RJ 45)
(Screw mounting only/ without claw)
Article No. E174



ANTENNA SOCKET OUTLET
FOR TV ONLY
Article No. E183




KEY CARD HOLDER SWITCH
10AX 250V~
Article No. E160 (one way)
Article No. E160/2W (two way/change over)




DO NOT DISTURB AND
MAKE-UP ROOM INDICATOR
230V~
Article No. E142




SOCKET OUTLET WITH HINGED COVER
16A 250V~
Article No. E152



DOUBLE SWITCH
10AX 250V~
Article No. E162




SINGLE SWITCH WITH
INDICATOR LAMP
10AX 250V~
Article No. E16C



INTERMEDIATE SWITCH
10AX 250V~
Article No. E16G




TELEPHONE SOCKET & SINGLE NETWORK
SOCKET OUTLET Cat. 5e
(Screw mounting only/ without claw)
Article No. E173




TV CABLE SOCKET OUTLET
F TYPE CONNECTOR
(Screw mounting only/ without claw)
Article No. E185




DO NOT DISTURB SWITCH
10AX 250V~
Article No. E163/DND




BRITISH STANDARD SOCKET OUTLET
WITH SWITCH, INDICATOR LAMP AND
CHILD PROTECTION
13A 250V~
Article No. E155



TRIPLE SWITCH
10AX 250V~
Article No. E16N



SINGLE CHANGE OVER SWITCH
WITH INDICATOR LAMP
10AX 250V~
Article No. E16D




DIMMER FOR INCANDESCENT
LAMP WITH PUSH ON PUSH OFF SWITCH
60 - 500W, 220V~
Article No. E191 (one way)
Article No. E191/2W (two way/change over)



DUAL TELEPHONE/
DUAL UNIVERSAL NETWORK
SOCKET OUTLETS (RJ45/RJ12/RJ11)
Article No. E176




ANTENNA SOCKET OUTLET
FOR TV AND RADIO SINGLE USE
Article No. E181




DO NOT DISTURB &
MAKE UP ROOM SWITCH
10AX 250V~
Article No. E16LD/DND-MUR



BRITISH STANDARD SOCKET OUTLET
WITH SWITCH AND CHILD PROTECTION
13A 250V~
Article No. E157



SINGLE CHANGE OVER SWITCH
10AX 250V~
Article No. E163



TWO POLE SWITCHES WITH
INDICATOR LAMP
20AX 250V~
Article No. E16F



DUAL USB CHARGING PORT
5VDC/2.1A 220V~
Article No. E196

NEW
PRODUCT

PLANO SERIES AVAILABLE IN 5 EXCLUSIVE COLORS



WHITE



PEARL WHITE



SILVER ALUMINIUM



HARVEST GOLD



BLACK METALLIC

The introduction of Plano Series with a wide selection of sockets & switches with extremely classy & modern look combined with product safety help meet a broad variety of applications in homes, apartment, offices and commercial environment.

Plano series are designated to fully comply with the international standards for this class of product and carry the international accreditation mark.